

DIGITAL SALT METER (GMK-525N / 545A / 555 / 555N)

DESCRIPTION OF THE INSTRUMENT



BEFORE MEASUREMENT

- 1) OPEN THE LID OF BATTERY COMPARTMENT (BACK SIDE).
- 2) WATCHING +/- POLES CAREFULLY, PLACE 1.5V (AAA) x 3EA IN IT.
- 3) IF MODEL NO. OF THE INSTRUMENT APPEARS ON LCD AND DISAPPEARS, THE UNIT IS READY TO MEASURE IN NORMAL CONDITION (AUTOMATIC CALIBRATION).

MEASUREMENT

- 1) PLACE TEST SAMPLE SOLUTION ENOUGH TO FILL 'SAMPLE WELL'
- 2) ACCORDING TO TEMPERATURE OF TEST SAMPLE SOLUTION, PRESS ONE TEMP. SELECT BUTTON ('NORMAL' OR 'HOT' OR 'COLD'), AND THE MEASUREMENT RESULT (SALT %) APPEARS ON LCD FOR ABOUT ONE MINUTE, (# IF THE TEST SAMPLE IS OUT OF MEASURING RANGE, 'Er H' SIGN APPEARS.)

IMPORTANT

- 1) BEFORE EVERY MEASUREMENT, CLEAN THE SAMPLE WELL WITH WATER & TISSUE.
- 2) WHEN LOW BATTERY SIGN APPEARS ON LCD, REPLACE THE BATTERIES SHORTLY.
- 3) DO NOT STORE THE INSTRUMENT AT DAMP PLACE.
- 4) IN CASE OF NO USE FOR A LONG TIME, MAKE SURE TO REMOVE THE BATTERIES.
- 5) WARRANTY PERIOD IS 12 MONTHS FROM THE DATE OF PURCHASE.
- 6) IN CASE OF WRONG USE, ABUSE OR MISUSE, WARRANTY WILL NOT BE GRANTED.

STANDARD ACCESSORIES

- 1) BATTERY 1.5 VOLT (AAA) : 3 EA
- 2) USER'S MANUAL : 1 EA
- 3) CASE : 1EA

G-WON HITECH CO., LTD.

WOOLIM E-BIZ. CENTER 310,
#170-5, GURO-DONG, GURO-GU,
SEOUL, KOREA(152-769)
Tel : 82-2-2108-1646(DIR.)
Fax : 82-2-2108-1649
E-MAIL : g-won@g-won.co.kr.

Other Instruments

- | | |
|-------------------------|--------------------------|
| ■ Digital Refractometer | ■ Tea Moisture Meter |
| ■ Wood Moisture Meter | ■ Coffee Moisture Meter |
| ■ Flour Moisture Meter | ■ Tobacco Moisture Meter |
| ■ Grain Moisture Meter | ■ Fruit Acidity Meter |

> BACK

> PRINT

☒ CLOSE

