



YASUDA
— TESTING THE LIMITS —

**No.605 PALMERTON TYPE SAMPLE
ADJUSTER | YASUDA SEIKI SEISAKUSHO
LTD. providing you the best material testing
equipment.**

No.605 PALMERTON TYPE SAMPLE ADJUSTER



This tester is used to adjust the thickness of vulcanized rubber for test preparation. The thickness of the rubber sample attached to the table is adjusted by moving sample table towards the abrasion wheel.

Specification

Sample Table	190 × 100 mm
Abrasion Wheel	Out-Diameter ϕ 5" , Thickness 2"
Stroke	U/D 70 mm, L/R 190 mm, B/F 50 mm (Manual)
Power Source	AC 200 V, 1-Phase, 10 A, 50/60 Hz
Dimensions/ Weight (Approx.)	W500 × D470 × H650 mm/ 100 kg