


Infrared Thermometer KEW 5515



temperature measurements

- Back light display helps to read in a dark place.
- Dual display: Main display shows the measured values and Sub display shows either of max, min, average or thermocouple value.
- Alarm function: The upper and lower temperature limits can be set.
- The red blinking back light indicates that the measured value is below or over the pre-set limits.

NL APS Canal

Temperature measurement with a K-type thermocouple is also possible.

KYORITSU ELECTRICAL INSTRUMENTS WORKS, LTD. www.kew-ltd.co.jp


Safety with non-contact

000

KEW 5515 Specifications

Display / Buttons

| Infrared Thermometer | |
|----------------------------------|--|
| Measuring range | -32 - 535°C |
| Accuracy | ±3.0°C (-3220 °C), ±2.0°C (-20 - +100°C), ±2%rdg (100 - 535°C) |
| Measuring element | Thermopile |
| Infrared spectral band | 5 - 14µm |
| Measuring diameter | 1000mm/ ø78mm (Distance/ Measuring dia.: 12:1) |
| Repeatability | Within ±1°C |
| Emissivity | Variable between 0.10 and 1.00 (by 0.01 steps), Before shipment: 0.95 |
| Collimation | Laser beam (630 - 670nm 1mW or less) specifies the center. |
| Thermocouple | |
| Thermocouple | K-type |
| Measuring range of thermocouple | -199 - 1372°C |
| Accuracy of thermocouple | ±1.5%rdg+1°C (-40 - 1372°C) |
| Response | 500ms |
| Resolution | 0.1°C |
| Auto power off | If no key is pressed for 6 seconds, the power is shut off automatically. |
| LCD display | LCD with back light (blinks in red when alarm function is activated) |
| Dual display | Simultaneous display (Measured value and either of max, min, average or thermocouple value.) |
| Operating temperature & humidity | 0 - 50°C/ 10 - 90% RH |
| Applicable standards | IEC 61326, IEC 61000-4-2, IEC 61000-4-3, IEC 61000-4-8 |
| Battery | 6F22(9V) × 1 |
| Dimension | 180 (L)×130 (W)×40 (D) mm |
| Weight | Approx. 195g (excluding battery) |
| Accessories | 9152(Carrying case), 6F22(9V) × 1, Instruction manual |




- Jpper/ Lower limit alarm [HAL/LAL]
- Cursor button (Down)
- **Buzzer button**
- SCAN/ HOLD/ AUTO
- Jnit
- Main display
- MAX/ MIN/ AVG
- Sub display
- Cursor button (Up)
- unction button





Relation of distance and measuring diameter



DANGER

The connector for thermocouple is not insulated. Do not make measurement using a thermocouple when there is a risk of electrical shock hazard.

WARNING

- KEW5515 is one of the portable laser applied instruments which are regulated by the consumer product safety law.
- Do not look into the laser beam.
- Do not aim the laser beam at human beings.
- Keep the instrument out of children's reach.



Please read the "Safety Warnings" in the instruction manual supplied with the instrument thoroughly and completely Safety Warnings : for correct use. Failure to follow the safety rules can cause fire, trouble, electrical shock, etc. Therefore, make sure to operate the instrument on a correct power supply and voltage rating marked on each instrument.

For inquires or orders :



2-5-20, Nakane, Meguro-ku, Tokyo, 152-0031 Japan Phone:+81-3-3723-0131 Fax:+81-3-3723-0152 E-mail:info-eng@kew-ltd.co.jp

www.kew-ltd.co.jp

